# BENTONE GEL® ISD V



# non-animal origin

# rheological additive

### for cosmetics and toiletries

#### **GENERAL INFORMATION**

BENTONE GEL ISD V is a specially prepared dispersion of an organically modified hectorite in Isododecane.

This grade is designed to impart rheological control and suspension to organic- and silicone-based cosmetics.

BENTONE GEL ISD V is also particularly useful in emulsions and can be used in "cold process" systems. It provides thermostable viscosity control of the emulsion's oil phase, improves application properties, enhances skin-feel by masking greasy or tacky components and imparts a pleasant residual silkiness to the skin. BENTONE GEL ISD V is an alternative to traditional polymer or cellulose-based thickeners for stabilising emulsions.

### **INGREDIENTS**

### INCI name:

Isododecane, Disteardimonium Hectorite, Propylene Carbonate

# **APPLICATIONS**

- Mascara
- Eye shadow
- Antiperspirants
- Creams and Lotions
- Sun Care products

#### **KEY PROPERTIES**

## **BENTONE GEL ISD V rheological additive**

### Non-animal origin

### Rheological control

- Predictable, reproducible and stable viscosity control
- Shear-thinning rheology
- Excellent suspension of pigments and actives
- Controlled alignment of special-effect pigments
- Thermostable viscosity raises apparent melting point and ensures cost-efficient use of UV filters
- Emulsion stabilization [w/o and o/w]

### Convenience

- Optimally pre-activated and dispersed organoclay
- Incorporates with medium-shear mixing
- Can be added at any convenient stage of manufacture
- Gives a high degree of formulating flexibility
- Provides highly reproducible results for multisite production requirements

### Acceptability

- Non-abrasive
- Provides smooth feel to skin
- Toxicologically safe ingredients

### CHEMICAL AND PHYSICAL DATA

Color / Form	Light buff
Viscosity, Brookfield Helipath, TF Spindle, Pa.s @ 2.5 rpm	1700 - 3000
% Ash Content	5.6 – 6.6
Infrared	To Match Standard
Microbial Content	Less than 100 cfu/g

<sup>&</sup>quot;Note: Microbial results are based on analysis of irradiated organoclay prior to gel formulation."

NOTE: The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warrantly, express or implied, including a warrantly of merchantability and fitness for use. Purchasers will be subject to a separate agreement which will not incorporate this document.

<sup>©</sup> Copyright 2012, Elementis Specialties, Inc. All rights reserved. Copying and/or downloading of this document or information therein for republication is not allowed unless prior written agreement is obtained from Elementis Specialties, Inc.



#### **INCORPORATION**

BENTONE GEL ISD V can be added at any convenient suitable stage during manufacturing cycle. BENTONE GEL additive is a very high viscosity, shear-thinning product. To ensure good homogeneous mixing is achieved, care must be taken to overcome the large viscosity differential existing between the BENTONE GEL and the other lower viscosity components. Choice of mixing equipment and the configuration within the mixing vessels are critical factors in developing the optimum performance of the BENTONE GEL additives. The use of medium- to high-shear mixing equipment is recommended.

# **Batch Processing**

### **Single Phase Systems**

Always add the BENTONE GEL, under shear, to a portion of the organic component or solvent with which it is most compatible. Mix until homogeneous before adding the other ingredients.

### Multi-Phase Systems e.g. emulsions

Treat as the single phase but always ensure the BENTONE GEL additive is thoroughly mixed in before the emulsification stage.

#### **Continuous Processing**

The BENTONE GEL should be added to the oil phase at any convenient point that meets the above guidelines for batch processing. In multimanifold systems, a flowable pre-mix of the BENTONE GEL with a compatible oil or solvent should be made in a side pot.

Where only lower-shear mixing equipment is available, stir the BENTONE GEL alone and then slowly add the most compatible component by portions, always ensuring the mixture remains homogeneous at each stage.

# **LEVELS OF USE**

The level of use of the BENTONE GEL will depend on the formulation. Suspension will be provided by 2.5-10.0% additions. In emulsions, thickening will occur in the oil phase only and emulsion

### **USA Head Office**

Elementis Specialties, Inc. 469 Old Trenton Road East Windsor, NJ 08512 USA

Tel.: +1 609 443 2500 Fax: +1 609 443 2422

### Europe

Elementis UK Ltd c/o Elementis GmbH Stolberger Strasse 370 50933 Cologne Germany Tel.: +49 221 2923 2000

Fax: +49 221 2923 2000

viscosities will be influenced by 3-5% additions. Novel emulsification effects can be achieved, giving light feel and lower viscosities. In some water-in-oil systems a reduction of surfactant may be achievable by the use of BENTONE GEL additive.

Higher levels of BENTONE GEL will have a greater viscosity influence and thermostable viscosity in single phase systems may be achieved by 10-25% additions.

#### **COMPATIBILITY**

BENTONE GEL additives can contribute greatly to a formulation's stability by improving the compatibility of other ingredients. Care should be taken to determine the compatibility of the BENTONE GEL additive with the oils, actives or surfactant ingredients within a formulation. The wide range of grades available allows selection of the optimal carrier and organoclay for each system.

### **TOXICITY**

Care is taken to ensure that the ingredients used in BENTONE GEL additives are not known to be injurious to health in any way and have been toxicologically tested to ensure their safety. However, the BENTONE GEL additives have not been subjected to testing involving the use of animals within the last 10 years.

### STORAGE TEMPERATURES

This product contains Isododecane. Store away from excessive heat.

#### **SHELF LIFE**

BENTONE GEL ISD V has a shelf life of 2 (two) years from date of manufacture.

# SAFETY

Before using this product, please consult our MSDS.

### Malaysia

Elementis Specialties, Inc. Lot PT 55, 64 & 65 Jalan Hulu Tinggi 26/6 Seksyen 26 40400 Shah Alam Selangor Darul Ehsan Malaysia

Tel.: +60 3 5191 9979 Fax: +60 3 5191 6811

### China

Deuchem (Shanghai) ChemicalCo., Ltd. 99, Lianyang Road Songjiang Industrial Zone Shanghai China 201613 Tel.: +86 21 5774 0348 Fax: +86 21 5774 3563