

4 Weddings And A Foundation

C-2011-02

DES	CP	IDT	ION

This water in oil foundation gives an amazingly soft application and feel to the skin.

ADVANTAGES

BENTONE® LUXE WO improves the consistency and stability of the formulation.

SPECIFICATIONS

<u>Viscosity:</u> DV-II. Spindle 5. 10rpm 7,500 cps

Appearance: Brown Lotion

Phase	Ingredient	Supplier	%w/w
Α	Isododecane (FANCOL® ID-CG)	Elementis	6.50
	Polyglyceryl-6 Polyricinoleate (and) Polyglyceryl-2 Isostearate (and) Disteardimonium Hectorite (BENTONE® LUXE WO)	Elementis	5.50
	Triethylhexanoin (Pelemol GTO)	Pheonix	5.00
	Coco-Caprylate/Caprate (Emolid CC)	IQL	4.00
	Polyglyceryl-4 Isostearate, Cetyl PEG/PPG-10/1 Dimethicone, Hexyl Laurate (Abil WE 09)	Evonik	3.00
	C12-15 Alkyl Benzoate (Cetiol AB)	BASF	3.00
	PEG-30 Dipolyhydroxystearate (Dehymuls LE)	BASF	2.00
	Phenyl Trimethicone (CPF-3300@40cSt)	Nusil	2.00
	Camellia Sinensis Leaf Oil (Camellia Oil)	Ikeda	1.00
В	Deionized Water		50.30
	Butylene Glycol		7.00
	Sorbitol	Merck	2.00
	Ethylhexylglycerin, Caprylyl Glycol (Sensiva SC10)	Schülke	0.60
С	Titanium Dioxide (and) Hydrogenated Stearyl Olive Esters (MyoNAT White)	Miyoshi Kasei	4.00
	Aluminium Starch Octenylsuccinate (Agenaflo OS 9051)	Agrana	2.00
	Yellow Iron Oxide (and) Hydrogenated Stearyl Olive Esters (MiyoNAT Yellow)	Miyoshi Kasei	1.70
	Red Iron Oxide (and) Hydrogenated Stearyl Olive Esters (MiyoNAT Red)	Miyoshi Kasei	0.20
	Black Iron Oxide (and) Hydrogenated Stearyl Olive Esters (MiyoNAT Black)	Miyoshi Kasei	0.20

Procedure:

- 1. Heat Phase A and Phase B separately to 75°C.
- 2. Add Phase C to Phase A with homogenizer and mix, then add Phase B and mix thoroughly. Cool with stirring.

Reference: 105-26

NOTE: The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchasers will be subject to a separate agreement which will not incorporate this document.

© Copyright 2018, Elementis Specialties, Inc. All rights reserved. Copying and/or downloading of this document or information therein for republication is not allowed unless prior written agreement is obtained from Elementis Specialties, Inc.

® Registered trademark of Elementis Specialties, Inc.

V02 April 2018

North America

Elementis 469 Old Trenton Road East Windsor, NJ 08512, USA Tel.: +1 609 443 2500 Fax: +1 609 443 2422

Europe

Elementis UK Ltd. c/o Elementis GmbH Stolberger Strasse 370 50933 Cologne, Germany Tel.: +49 221 2923 2066 Fax: +49 221 2923 2011

Asia

Deuchem (Shanghai) Chemical Co., Ltd. 99, Lianyang Road Songjiang Industrial Zone Shanghai, China 201613 Tel.: +86 21 5774 0348 Fax: +86 21 5774 3563