

Cashmere Custard Creme

F-2021-02

DESCRIPTION

Dig in! A delightful bouncy moisturizer with cool memory effect yet feather light on application. Serum and moisturizing benefits in one. **RHEOLUXE® 880** creates a "memorable" experience.

ADVANTAGES

RHEOLUXE® 880 gives the formulation its unique texture.

MEADOWESTOLIDE® has been shown to improve moisturization.

SPECIFICATIONS

Viscosity: DV-II. Spindle 7. 100rpm
20,000 cps

pH: 5.0-6.0

Appearance: Light purple custard like cream

Phase	Ingredient	Supplier	%w/w
A	Deionized Water		83.20
	1, 3-Propanediol	Alfa Aesar	2.00
	Sodium Hylauronate (Hyacare 50 1% in Water)	Evonik	1.00
	Ascopyllum Nodosum Extract (and) Asparagopsis Armata Extract (Aldavine 5x)	Lucas Meyer	1.00
	Caprylyl Glycol (and) Ethylhexylglycerin (Sensiva SC10)	Schülke & Mayr	1.00
	CI 16035 (1% SunCroma C46-9393 Violet in Water)	Sun Chemical	0.20
B	PEG-40 Hydrogenated Castor Oil (Tagat CH40)	Evonik	4.00
	Dimethicone (KF-96L-2cs)	Shin Etsu	2.00
	Caprylic/Capric Triglyceride (Palmerest 3575)	KLK Oleo	2.00
	Meadowfoam Estolide (MEADOWESTOLIDE®)	Elementis	0.50
C	Sodium Acrylates Copolymer (and) Lecithin (Lecigel)	Lucas Meyer	1.00
D	Bis-C16-20 Isoalkoxy TMHDI/PEG-90 Copolymer (RHEOLUXE® 880)	Elementis	1.50
	Fragrance (Candy Girl)	Spinnrad	0.10
E	Citric Acid		TMS

Procedure:

1. Combine Phase A mix with a homogenizer.
2. Combine Phase B and heat to 40°C.
3. Add Phase B to Phase A with homogenizer and mix until uniform.
4. Add Phase C to combined Phase A/B with homogenizer mixing. Mix for 15 minutes.
5. Transfer to propeller mixing and add Phase D. Mix for 10 minutes.
6. Adjust pH using Phase E.

Reference: 102-96

NOTE: The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchasers will be subject to a separate agreement which will not incorporate this document.

© Copyright 2018, Elementis Specialties, Inc. All rights reserved. Copying and/or downloading of this document or information therein for republication is not allowed unless prior written agreement is obtained from Elementis Specialties, Inc.

© Registered trademark of Elementis Specialties, Inc.

V02 March 2018

North America

Elementis Specialties, Inc.
469 Old Trenton Road
East Windsor, NJ 08512, USA
Tel.: +1 609 443 2500
Fax: +1 609 443 2422

Europe

Elementis UK Ltd.
c/o Elementis GmbH
Stolberger Strasse 370
50933 Cologne, Germany
Tel.: +49 221 2923 2066
Fax: +49 221 2923 2011

Asia

Deuchem (Shanghai) Chemical Co., Ltd.
99, Lianyang Road
Songjiang Industrial Zone
Shanghai, China 201613
Tel.: +86 21 5774 0348
Fax: +86 21 5774 3563