

From Dawn Till Dusk Lip Tattoo - Pink

C-2010-02

DESCRIPTION

Apply thickly to the lips, being careful to distribute it evenly inside on the lip line. Leave to dry for 15 minutes then peel and rub off. This product leaves a lip coloring tattoo effect on the lips.

ADVANTAGES

RHEOLUXE® 812 improves the application on the lips and the peel-off effect.

SPECIFICATIONS

Viscosity: DV-II. Spindle 6. 100 rpm, 2020 cps

pH: 5.0-6.0

Appearance: Thick red paste

Phase	Ingredient	Supplier	%w/w
A	Deionized Water		61.10
	Polyvinyl Alcohol (Selvol Ultalux FA)	Sekisui Specialties	7.00
	Polyvinyl Alcohol (Selvol Ultalux AD)	Sekisui Specialties	5.00
	Butylene Glycol		5.00
B	Deionized Water		12.00
	CI 17200 (D&C Red No.33)	Sun Chemical	1.30
	CI 15985 (FD&C Yellow No. 6)	Sun Chemical	0.70
C	Ethanol SD 40		5.50
	Butylene Glycol (and) Water (and) Aronia Arbutifolia Extract (Chokeberry Extract BG PF SF)	Active Concepts	1.00
	Caprylyl Glycol (and) Ethylhexylglycerin (Sensiva SC10)	Schulke & Mayr	0.60
	Vanilla Fragrance		0.10
D	Bis-Lauryl Cocaminopropylamine/HDI/PEG-100 Copolymer (and) Butylene Glycol (RHEOLUXE® 812)	Elementis	0.70
E	Citric Acid		q.s

Procedure:

1. Heat Phase A to 85°C with mixing. Mix for 2 minutes using the Silverson mixer.
2. Warm Phase B until pigments have dissolved.
3. Using propeller mixing add Phase B to Phase A and stir.
4. Cool with stirring and add Phase C at 35°C.
5. Add Phase D with mixing for 10 minutes.
6. Adjust pH to 5.0-6.0 with Phase E.

Reference: 105-18

NOTE: The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchasers will be subject to a separate agreement which will not incorporate this document.

© Copyright 2018, Elementis Specialties, Inc. All rights reserved. Copying and/or downloading of this document or information therein for republication is not allowed unless prior written agreement is obtained from Elementis Specialties, Inc.

® Registered trademark of Elementis Specialties, Inc.

V02 April 2018

North America

Elementis
469 Old Trenton Road
East Windsor, NJ 08512, USA
Tel.: +1 609 443 2500
Fax: +1 609 443 2422

Europe

Elementis UK Ltd.
c/o Elementis GmbH
Stolberger Strasse 370
50933 Cologne, Germany
Tel.: +49 221 2923 2066
Fax: +49 221 2923 2011

Asia

Deuchem (Shanghai) Chemical Co., Ltd.
99, Lianyang Road
Songjiang Industrial Zone
Shanghai, China 201613
Tel.: +86 21 5774 0348
Fax: +86 21 5774 3563