

## The Primer Awakens

C-2015-02

### DESCRIPTION

A refreshing facial moisturizer to waken you up in the morning with a priming effect to give the skin an even finish before application of a foundation.

### ADVANTAGES

**BENTONE® LUXE WS** improves emulsion stability, while enhancing application.

### SPECIFICATIONS

Viscosity: DV-II. Spindle 7. 10rpm  
88,400 cps

Appearance: Thick white shimmery cream

Phase	Ingredient	Supplier	%w/w
A	Deionized Water		60.30
	Butylene Glycol		0.50
B	Isododecane ( <b>FANCOL® ID-CG</b> )	<b>Elementis</b>	10.00
	Cyclopentasiloxane (Mirasil CM5)	Bluestar	5.00
	Steareth-2 (Emulgin S2)	BASF	0.50
C	Titanium Dioxide (and) Mica (Flamenco Summit Red R30D)	BASF	2.00
D	Dimethicone/Vinyl Dimethicone Crosspolymer (and) Butylene Glycol (and) Silica (Dowsil EP-9801 Hydro Cosmetic Powder)	Dow Corning	5.00
E	Cyclopentasiloxane (and) PEG-10 Dimethicone (and) Distearidimonium Hectorite ( <b>BENTONE® LUXE WS</b> )	<b>Elementis</b>	5.00
	Dimethicone (and) Dimethicone Crosspolymer (Dowsil 9041 Silicone Elastomer Blend)	Dow Corning	7.00
	Cyclopentasiloxane (and) C30-40 Alkyl Cetearyl Dimethicone Crosspolymer (Velvisil 125)	Momentive	3.00
F	Glycerin (and) Water (and) Arthrospira Platensis Extract (Spirulina in Glycerin)	Bio-Botanica	1.00
	Dehydroacetic Acid (and) Benzoic Acid (and) Phenoxyethanol (Sharonmix 700)	SLI Chemical	0.50
	Sodium Hylauronate (Hyacare 1% Solution in Water)	Evonik	0.20

### Procedure:

1. Combine Phase A with mixing.
2. Heat Phase B to 50°C and add Phase C and mix.
3. Using the propeller mixer add Phase D to Phase B/C and mix till fully dispersed.
4. Add Phase E individually and mix with high speed stirring till uniform.
5. Add Phase A to Phase B/C/D/E slowly and mix until uniform.
6. At 30°C add Phase F and mix till uniform.

Reference: 102-84

*NOTE: The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchasers will be subject to a separate agreement which will not incorporate this document.*

© Copyright 2018, Elementis Specialties, Inc. All rights reserved. Copying and/or downloading of this document or information therein for republication is not allowed unless prior written agreement is obtained from Elementis Specialties, Inc.

© Registered trademark of Elementis Specialties, Inc.

V02 April 2018

#### North America

Elementis  
469 Old Trenton Road  
East Windsor, NJ 08512, USA  
Tel.: +1 609 443 2500  
Fax: +1 609 443 2422

#### Europe

Elementis UK Ltd.  
c/o Elementis GmbH  
Stolberger Strasse 370  
50933 Cologne, Germany  
Tel.: +49 221 2923 2066  
Fax: +49 221 2923 2011

#### Asia

Deuchem (Shanghai) Chemical Co., Ltd.  
99, Lianyang Road  
Songjiang Industrial Zone  
Shanghai, China 201613  
Tel.: +86 21 5774 0348  
Fax: +86 21 5774 3563