



**MOMENTIVE™**  
 inventing possibilities

Aqua Blur  
 Featuring: Silsoft\* EAU microgel

COLOR COSMETICS

Silsoft EAU microgel helps generate unexpected 'splash' sensory in formulations. Upon application, the formulation separates releasing water, resulting in a fresh, light sensory experience. Tospearl\* microspheres enhance light scattering allowing the formulator to enhance soft focus properties of his formulation. Silsoft Silicone gel can help improve the sensory aesthetics of tacky formulations.

Phase	Ingredients	INCI Name	Wt (%)
A	Water	Aqua	Up to 100
	Glycerin	Glycerin	5.0
B	<b>Silsoft Silicone Gel</b> (1)	Cyclopentasiloxane (and) Cetearyl Dimethicone/Vinyl Dimethicone Crosspolymer	3.0
	<b>Silsoft EAU microgel</b> (1)	Polysilicone-34 and Isononyl Isononanoate (and) Water	3.0
	<b>Tospearl 3000A microspheres</b> (1)	Polymethylsilsesquioxane	2.0
C	Preservative	Preservative	Qs
D	Fragrance	Fragrance	Qs

**Procedure:**

1. Combine ingredients of phase A;
2. Combine ingredients pf phase B and mix well;
3. Add phase (A) to phase (B) and homogenize until uniform (Ultra-Turrax † or Cowles mixer);
4. Add ingredients of phase C and mix until homogeneous;
5. Add ingredients of phase D and mix until homogeneous.

**Typical Physical Properties:**

Appearance: white gel cream  
 pH: 6.7  
 Viscosity: 41,000 cP (DV2T RV Helipath, spindle 93)  
 Stability: 30 days, 45°C

Typical properties are average test data, may vary and are not to be used as or to develop specifications.

\*Trademark of Momentive Performance Materials Inc. or its affiliates.  
 †Trademarks of their respective owners.

# Aqua Blur

## Featuring: Silsoft\* EAU microgel

COLOR COSMETICS

### Suppliers:

1. Momentive Performance Materials

#### Worldwide

commercial.services@momentive.com  
T +1 614 986 2495  
T +1 800 295 2392

For literature and technical assistance,  
visit our website at:  
[www.momentive.com](http://www.momentive.com)

#### Latin America

South America  
T +55 11 4534 9660

#### Europe, Middle East, Africa and India

T +00 800 4321 1000  
T +40 213 044229

#### Pacific

China  
T +800 820 0202

Japan  
T +81 276 20 6182

All Other Countries  
T +60 3 9206 1543

### Important Information and Disclaimers

**FORMULATIONS ARE ILLUSTRATIVE EXAMPLES AND DO NOT REPRESENT COMMERCIALIZED PRODUCTS.** They have not been subjected to extensive testing and Momentive makes no representation or warranty of any kind with regard to any such formulations, including, without limitation, concerning the performance, efficacy or safety of any product manufactured using such formulations. **EACH USER BEARS FULL RESPONSIBILITY FOR (1) MAKING ITS OWN DETERMINATION AS TO THE SUITABILITY AND LEGAL COMPLIANCE OF ANY FORMULATION, MATERIALS, RECOMMENDATIONS, OR ADVICE FOR ITS OWN PARTICULAR USE, (2) IDENTIFYING AND PERFORMING ALL TESTS AND ANALYSES NECESSARY TO ASSURE THAT ITS FINISHED PRODUCTS BASED UPON EXAMPLE FORMULATIONS AND/OR INCORPORATING MENTIONED PRODUCTS, MATERIALS, OR SERVICES WILL BE SAFE AND SUITABLE FOR USE UNDER END-USE CONDITIONS, AND (3) OBTAINING ANY NECESSARY GOVERNMENT OR REGULATORY CLEARANCE, LICENSE OR REGISTRATION.**

Any reference to a third party's materials is not an endorsement of those materials or an endorsement by the third party of Momentive materials. Momentive has not undertaken a patent or other intellectual property search on the formulations. No statement contained herein concerning a possible or suggested use of any material, product, service or design is intended, or should be construed, to grant any license under any patent or other intellectual property right covering such use or design, or as a recommendation for the use of such material, product, service or design in the infringement of any patent or other intellectual property right.

**BEFORE HANDLING ANY PRODUCTS MENTIONED, REVIEW THE LATEST SAFETY DATA SHEET (SDS) AND LABEL FOR PRODUCT SAFETY INFORMATION, SAFE HANDLING INSTRUCTIONS, PERSONAL PROTECTIVE EQUIPMENT IF NECESSARY, EMERGENCY SERVICE CONTACT INFORMATION, AND ANY SPECIAL STORAGE CONDITIONS REQUIRED FOR SAFETY. MOMENTIVE MAINTAINS AN AROUND-THE-CLOCK EMERGENCY SERVICE FOR ITS PRODUCTS. SDS FOR MOMENTIVE PRODUCTS ARE AVAILABLE AT [WWW.MOMENTIVE.COM](http://WWW.MOMENTIVE.COM) OR, UPON REQUEST, FROM ANY MOMENTIVE REPRESENTATIVE. USE OF OTHER MATERIALS IN CONJUNCTION WITH MOMENTIVE PRODUCTS MAY REQUIRE ADDITIONAL PRECAUTIONS. PLEASE REVIEW AND FOLLOW THE SAFETY INFORMATION PROVIDED BY THE MANUFACTURER OF SUCH OTHER MATERIALS.**

**THE MATERIALS, PRODUCTS AND SERVICES OF MOMENTIVE PERFORMANCE MATERIALS INC. AND ITS SUBSIDIARIES AND AFFILIATES (COLLECTIVELY "SUPPLIER"), ARE SOLD SUBJECT TO SUPPLIER'S STANDARD CONDITIONS OF SALE, WHICH ARE INCLUDED IN THE APPLICABLE DISTRIBUTOR OR OTHER SALES AGREEMENT, PRINTED ON THE BACK OF ORDER ACKNOWLEDGMENTS AND INVOICES, AND AVAILABLE UPON REQUEST. EXCEPT AS PROVIDED IN SUPPLIER'S STANDARD CONDITIONS OF SALE, SUPPLIER AND ITS REPRESENTATIVES SHALL IN NO EVENT BE RESPONSIBLE FOR ANY LOSS RESULTING FROM ANY USE OF ITS MATERIALS, PRODUCTS OR SERVICES DESCRIBED HEREIN.** Nothing in this or any other document, nor any oral recommendation or advice, shall be deemed to alter, vary, supersede, or waive any provision of Supplier's standard Conditions of Sale or this Disclaimer, unless any such modification is specifically agreed to in a writing signed by Supplier.

\*Trademark of Momentive Performance Materials Inc. or its affiliates.

Momentive and the Momentive logo are trademarks of Momentive Performance Materials Inc.

All trademarks other than those owned by Momentive Performance Materials Inc. or its affiliates are owned by their respective owners.

Copyright 2016 Momentive Performance Materials Inc. All rights reserved.

Revised: Feb 2018

Personal Care Formulary LA (MU-054/17-Rev.02)